# HOW-TO Integration with smart-me

## **Important Note**

Cloud2Cloud integration requires a license. Please visit www.whatwatt.ch/pricing for more information.



Version 1.0

Date 13/10/2025

whatwatt.ch info@whatwatt.ch



## 1. Introduction

Your whatwatt Go can send telemetry to smart-me. The key features are:


- Cloud2Cloud integration Telemetry reports from the smart meters are forwarded by whatwatt Go devices to whatwatt Cloud and near real-time to smart-me cloud.
- Integration setup Integration is on account level. It has to be enabled and configured in the smartme portal for the specific whatwatt account.
- Once enabled "real-time" telemetry data from whatwatt are visible on smart-me portal.

### Important note


Cloud2Cloud integration requires a license. Please visit www.whatwatt.ch/pricing for more information.

# 2. Setup


- 1. Login to your smart-me account on the smart-me portal
- 2. Go the "API" section and then to "Api keys"



3. Select "Create new" on the "Api keys" view



4. Create a new API token - Select "device.readwrite" only



- 5. Copy and securely store the generated API token
- 6. Send the generated API token to whatwatt support Use the contact form
- 7. whatwatt will confirm the integration once it is done. Once confirmed telemetry data of your whatwatt devices are available in the smart-me portal See "Dashboard" > "Meters" > "List of whatwatt Go's" identified by whatwatt Go MAC/ID.

